TRC-190 Series

Rackmount chassis for the NRack System™



- > 19 slots for high density applications
- > Supports hot-swap and dual power input with redundancy
- > Fan-less chassis design reduces repair time















Introduction

The TRC-190 series provides 19 slots for media converter modules such as the TCF-142-RM series. A TRC-190 chassis comes with one AC or DC power input, with an optional redundant power expansion

module available for greater reliability. The TRC-190 series' power input module supports the hot-swap feature.

: Specifications

Physical Characteristics

Housing: SECC (1.2 mm)

Dimensions: 440 x 260 x 77 mm (18.6 x 11 x 3.3 in) Weight: 5.2 kg (11.4 lbs), with one power module installed Number of Slots: 19 slots in the front for slide-in modules, 2 slots in the back for power supply modules

Environmental Limits

Operating Temperature: 0 to 60°C (32 to 140°F)

Operating Humidity: 5 to 95% RH

Storage Temperature: -20 to 75°C (-4 to 158°F)

Power Requirements

Input Voltage: Universal 100 to 240 VAC (47 to 63 Hz) or 12 to 48

VDC

Power Consumption: Max. Output: 5.4 A @ 12 V

Regulatory Approvals

CE: Class A


FCC: Part 15 sub part B Class A EMI: EN55022 2006, Class B

EN61000-4-2 (ESD), Criteria A, Level 4 EN61000-4-3 (RS), Criteria A, Level 2 EN61000-4-4 (EFT), Criteria A, Level 3 EN61000-4-5 (Surge), Criteria A, Level 3 EN61000-4-6 (CS), Criteria A, Level 2 EN61000-4-8 (PFMF), Criteria A, Level 3 EN61000-4-11 (DIPS), Criteria A

Warranty

Warranty Period: 5 years

Details: See www.moxa.com/warranty



Constraint of the Constraint of the Constraint

Available Models

TRC-190-AC: Rack chassis, 2U, single 110 to 240 VAC input, with 19 slots on front panel

TRC-190-DC: Rack chassis, 2U, single 12 to 48 VDC input, with 19 slots on front panel (coming soon)

Optional Accessories (can be purchased separately)

PWR-190-AC: Redundant power supply, 110 to 240 VAC

PWR-190-DC: Redundant power supply, 12 to 48 VDC (coming soon)

Plate-1: Face plate to cover unused front panel slots (required for all unused slots)

Package Checklist -

- TRC-190 with single power input
- Power cord (for TRC-190-AC only)
- 18 face plates
- User's Manual (printed)
- · Warranty Card