



Sample image

Datasheet

Article number: 70023747

Designation: KG32.K400.*KL10.DE11

Description: Switchgear

Rated insulation voltage Ui							
			Voltage (V) AC / E	DC .			
			690 AC				
Rated uninterrupted current lu							
Current (A)	Ambient temperature (°C)	Peak temperatu	ure (°C) additional r				
32 Rated operational current le	50		55 Ambient te	mperature +50°C	during 24 hours v	vith peaks up to +55°C	
Utilization category				Vo	Itage (V)		Current
AC-32A				VC	20 - 400		Current
Rated operational power					20 400		
Utilization category		Voltage (V)	,	No. of phases		No. of poles	Power (F
AC-3		220 - 240		3		3	
AC-3		380 - 440		3		3	7
AC-3		660 - 690		3		3	7
AC-23A		220 - 240		3		3	5
AC-23A		380 - 440		3		3	
AC-23A		660 - 690		3		3	
Max. Fuse rating IEC							
Fuse characteristic					No. of Fu		Current
gG						1	
UL60947-4-1, UL508							
Nominal Voltage							
			Voltage (V) AC / L	DC .			
			600 AC				
Rated insulation voltage Ui				_			
rated insulation voltage Ui			Voltage (V) AC / L	DC .			
				DC .			
Rated insulation voltage Ui	Current	(4)	Voltage (V) AC / L		atura (°C) Additio	inal Toyt	
-	Current		Voltage (V) AC / L	OC Ambient tempera		nal Text	
Rated thermal current		(A) 30	Voltage (V) AC / L		nture (°C) Additio 0 - 40 —	nal Text	
Rated thermal current Horsepower rating			Voltage (V) AC / L			nal Text Power (HP)	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting			Voltage (V) AC / E 600 AC	Ambient tempera	0-40 -		Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL			Voltage (V) AC / L 600 AC	Ambient tempera	0-40 - No. of poles	Power (HP)	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL DOL			Voltage (V) AC / L 600 AC Voltage (V) 110-120 200-208 220-240	Ambient tempera No. of phases 1	0-40 No. of poles 2 2 2	Power (HP) 1,50	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL DOL DOL DOL			Voltage (V) AC / L 600 AC Voltage (V) 110-120 200-208	Ambient tempera No. of phases 1	0-40 No. of poles 2 2 2 2 2	Power (HP) 1,50 3 5 5	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL DOL DOL DOL DOL DOL DOL			Voltage (V) AC / E 600 AC Voltage (V) 110 - 120 200 - 208 220 - 240 277 - 277 415 - 415	Ambient tempera No. of phases 1 1 1	0-40 - No. of poles 2 2 2 2 2 2	Power (HP) 1,50 3 5 5 5	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL DOL DOL DOL DOL DOL DOL DOL DOL			Voltage (V) AC / L 600 AC Voltage (V) 110-120 200-208 220-240 277-277 415-415 440-480	No. of phases 1 1 1 1 1 1 1	0-40 - No. of poles 2 2 2 2 2 2 2 2 2	Power (HP) 1,50 3 5 5 5 7,50	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL			Voltage (V) AC / L 600 AC Voltage (V) 110-120 200-208 220-240 277-277 415-415 440-480 550-600	No. of phases 1 1 1 1 1 1 1 1	0-40 - No. of poles 2 2 2 2 2 2 2 2 2 2 2	Power (HP) 1,50 3 5 5 7,50 7,50	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL			Voltage (V) AC / E 600 AC Voltage (V) 110-120 200-208 220-240 277-277 415-415 440-480 550-600 110-120	No. of phases 1 1 1 1 1 3	0-40 - No. of poles 2 2 2 2 2 2 2 3	Power (HP) 1,50 3 5 5 5 7,50 7,50 3	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL			Voltage (V) AC / E 600 AC Voltage (V) 110 - 120 200 - 208 220 - 240 277 - 277 415 - 415 440 - 480 550 - 600 110 - 120 200 - 240	No. of phases 1 1 1 1 1 1 1 3 3	0-40 - No. of poles 2 2 2 2 2 2 2 2 3 3 3	Power (HP) 1,50 3 5 5 5 7,50 7,50 3 10	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL			Voltage (V) AC / L 600 AC Voltage (V) 110 - 120 200 - 208 220 - 240 277 - 277 415 - 415 440 - 480 550 - 600 110 - 120 200 - 240 415 - 415	No. of phases 1 1 1 1 1 1 1 1 3 3 3 3	0-40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3	Power (HP) 1,50 3 5 5 7,50 7,50 3 10 10	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL			Voltage (V) AC / E 600 AC Voltage (V) 110-120 200-208 220-240 277-277 415-415 440-480 110-120 200-240 415-415 440-480	No. of phases 1 1 1 1 1 3 3 3 3 3 3	0-40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3 3 3	Power (HP) 1,50 3 5 5 5 7,50 7,50 3 10 10 20	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL			Voltage (V) AC / L 600 AC Voltage (V) 110 - 120 200 - 208 220 - 240 277 - 277 415 - 415 440 - 480 550 - 600 110 - 120 200 - 240 415 - 415	No. of phases 1 1 1 1 1 1 1 1 3 3 3 3	0-40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3	Power (HP) 1,50 3 5 5 7,50 7,50 3 10 10	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL			Voltage (V) AC / E 600 AC Voltage (V) 110-120 200-208 220-240 277-277 415-415 440-480 110-120 200-240 415-415 440-480	No. of phases 1 1 1 1 1 3 3 3 3 3 3	0-40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3 3 3	Power (HP) 1,50 3 5 5 5 7,50 7,50 3 10 10 20	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL			Voltage (V) AC / E 600 AC Voltage (V) 110-120 200-208 220-240 277-277 415-415 440-480 110-120 200-240 415-415 440-480	No. of phases 1 1 1 1 1 3 3 3 3 3 3	0-40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3 3 3	Power (HP) 1,50 3 5 5 5 7,50 7,50 3 10 10 20	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL			Voltage (V) AC / E 600 AC Voltage (V) 110-120 200-208 220-240 277-277 415-415 440-480 110-120 200-240 415-415 440-480	No. of phases 1 1 1 1 1 3 3 3 3 3 3	0-40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3 3 3	Power (HP) 1,50 3 5 5 5 7,50 7,50 3 10 10 20	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL			Voltage (V) AC / E 600 AC Voltage (V) 110-120 200-208 220-240 277-277 415-415 440-480 110-120 200-240 415-415 440-480	No. of phases 1 1 1 1 1 3 3 3 3 3 3	0-40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3 3 3	Power (HP) 1,50 3 5 5 5 7,50 7,50 3 10 10 20	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL		30	Voltage (V) AC / E 600 AC Voltage (V) 110 - 120 200 - 208 220 - 240 277 - 277 415 - 415 440 - 480 550 - 600 110 - 120 200 - 240 415 - 415 440 - 480 550 - 600	No. of phases 1 1 1 1 1 3 3 3 3 3	0-40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3 3	Power (HP) 1,50 3 5 5 5 7,50 7,50 3 10 10 20 25	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL		not more than 10kA rms	Voltage (V) AC / E 600 AC Voltage (V) 110 - 120 200 - 208 220 - 240 277 - 277 415 - 415 440 - 480 550 - 600 110 - 120 200 - 240 415 - 415 440 - 480 550 - 600	No. of phases 1 1 1 1 1 1 3 3 3 3 3 res, 600V ac max.	0 - 40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3 3 when protected	Power (HP) 1,50 3 5 5 7,50 7,50 3 10 10 20 25	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL	on circuits capable of delivering	not more than 10kA rms	Voltage (V) AC / E 600 AC Voltage (V) 110 - 120 200 - 208 220 - 240 277 - 277 415 - 415 440 - 480 550 - 600 110 - 120 200 - 240 415 - 415 440 - 480 550 - 600	No. of phases 1 1 1 1 1 1 3 3 3 3 3 res, 600V ac max.	0 - 40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3 3 when protected	Power (HP) 1,50 3 5 5 7,50 7,50 3 10 10 20 25	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL	on circuits capable of delivering	not more than 10kA rms n 65000 rms symmetrica	Voltage (V) AC / E 600 AC Voltage (V) 110 - 120 200 - 208 220 - 240 277 - 277 415 - 415 440 - 480 550 - 600 110 - 120 200 - 240 415 - 415 440 - 480 550 - 600	No. of phases 1 1 1 1 1 3 3 3 3 3 res, 600V ac max., when protect	0 - 40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3 3 when protected	Power (HP) 1,50 3 5 5 7,50 7,50 3 10 10 20 25	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL	on circuits capable of delivering pable of delivering not more tha	not more than 10kA rms n 65000 rms symmetrics °C)	Voltage (V) AC / E 600 AC Voltage (V) 110 - 120 200 - 208 220 - 240 277 - 277 415 - 415 440 - 480 550 - 600 110 - 120 200 - 240 415 - 415 440 - 480 550 - 600	No. of phases 1 1 1 1 1 3 3 3 3 3 res, 600V ac max., when protect	0 - 40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3 3 3 when protected	Power (HP) 1,50 3 5 5 7,50 7,50 3 10 10 20 25	Ambient temperature
Rated thermal current Horsepower rating Across-the-Line Motor Starting DOL	on circuits capable of delivering pable of delivering not more that Temperature rating (60 -	not more than 10kA rms n 65000 rms symmetrics °C)	Voltage (V) AC / E 600 AC Voltage (V) 110 - 120 200 - 208 220 - 240 277 - 277 415 - 415 440 - 480 550 - 600 110 - 120 200 - 240 415 - 415 440 - 480 550 - 600	No. of phases 1 1 1 1 1 3 3 3 3 3 res, 600V ac max., when protect	0 - 40 - No. of poles 2 2 2 2 2 2 2 3 3 3 3 3 3 3 when protected eted by 40A Class	Power (HP) 1,50 3 5 5 7,50 7,50 3 10 10 20 25	Ambient temperature Ambient temperature



General Use									
	Itage (V)	Current (A)	No. of phases	No. of pol	es			No. of contacts	in series
/C	600	30	1		2				1
C	600	30	3		3				1
General Information Text									
	d position inc	licating means	to be used with these manua	I motor controllers sho	uld be provided from	the manufacture	r. or the operating	handle and position indication	ng means
			combination with the manua		a.a.a.a p. a		., o op o	,	.9
When intended for use as	s a motor dis	connector the o	levice shall be provided with	a method of being lock	ed in the OFF-position				
CSA									
Nominal Voltage									
Ť				Voltage (V) AC / L	DC				
				600 AC					
Rated insulation voltage U	Ji								
				Voltage (V) AC / I	DC				
Rated thermal current				600 AC					
Nated thermal current			Current (A)		Ambient temperature	e (°C) Additiona	l Text		
			30			0-40 -			
Horsepower rating									
Across-the-Line Motor Star	rting			Voltage (V)	•	lo. of poles	Power (HP)	Ambient temper	
DOL				110-120	1	2	1,50		40
DOL DOL				220 - 240 277 - 277	1 1	2	5 5		40 40
DOL				415-415	1	2	5		40
DOL				440 - 480	1	2	7,50		40
DOL				550 - 600	1	2	7,50		40
DOL				110 - 120	3	3	3		40
DOL				220 - 240	3	3	10		40
DOL				415-415	3	3	10		40
DOL DOL				440 - 480 550 - 600	3	3	20 25		40 40
Pilot duty rating code				550 - 600	3	ა	25		40
Duty Code									
A600									
Temp. rating of wire									
		Temperatur			Curre	nt (A) Text			
<u> </u>			75						
General Use AC / DC Vo	Itage (V)	Current (A)	No. of phases	No. of pol	00			No. of contacts	in porion
AC / DC VO	277	30	No. or priases	No. or por	1			No. or contacts	1 301105
AC	600	30	1		2				1
AC	600	30	3		3				1
GENERAL TECHNIC	AL INFOR	RMATION							
Size of conductor									
						Cross section (n	nm²) or		
composition of conductor			Min. / Max. value	No. of co	onductor per terminal			Material of the wire	
Solid wire Solid wire			Min. Min.			0.75mm ² 0.5mm ²		Copper Copper	
Flexible wire			Min.			0.75mm²		Copper	
Flexible wire			Max.			AWG 10		Copper	
Flexible wire			Max.			4mm²		Copper	
Flexible wire			Min.		1	1.5mm²		Copper	
Single-core or stranded wi			Max.			6mm²		Copper	
Single-core or stranded wi	ire		Max.			AWG 10		Copper	
Flexible wire with sleeve		NN 46000	Max.			4mm²		Copper	
Flexible wire with ferrule a Flexible wire with ferrule a			Min.			0.75mm ² 0.5mm ²		Copper Copper	
Stripping length	unig tu L	0440				S.Omili		ооррог	
				Length (mm)					
				Ē					
				9					
Recommended screw driv	ver				1-				
Type of screw driver				Value		_	_		
Cross Screwdriver				PH2					
Slot screwdriver according				0,8x4					
Tightening torque of screen	ws		41-1-1	ning targue (Al)				diahaania	(/h :- \
			tighte	ning torque (Nm) 1,25				tightening tord	que (lb-in) 11
				1,43					- 11
Approbations									Marking
									g
Specification									FAI
Specification									EAC
Specification									EAL
									EHI €
Specification EAC									(€
Specification EAC									




Approbations Marking Specification CUL)US UL 60947-4-1; CSA C22.2 No. 60947-4-1 (B) CSA C.22.2 No.14 GB/T14048. GB/T14048.3

General Information

- Use only copper wires with or without tinned/silver-plated individual wires. Soldering the end of the wire before wiring is not allowed.
- EMC Note: This device is suitable for use in environment A and B.
- -Terminals with factory fitted jumper links are tightened during production for loss prevention. When opening the terminal clamps, make sure that no factory fitted links get lost and that all wire
- After wiring, ALL terminal screws must be tightened to the specified torque values.
- The protection class of the selected mounting type may vary if optional extras are used.
- Do not lubricate or treat contacts.

- Switches may only be mounted, connected and set into operation by qualified persons according to the accepted rules of technology.							
Waste Electrical & Electronic Equipment (WEEE)							
Picture name	Description						
Z.	Do not throw in the trash as care must be taken to ensure environmentally sound disposal and recycling. Please either use an environmentally friendly waste disposal company; return to the supplier for disposal; or return direct to the manufacturer, Kraus & Naimer. You can find local Kraus & Naimer offices at www.krausnaimer.com						
Proposition 65							
Picture name	Description						
\triangle	WARNING: This product can expose you to chemicals including nickel and lead, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov.						

Classification Contact: Rigid contact bridge Classification Contact Mat: Silver Classification Terminal: Screw terminal






Wiring diagram KG32.K400.KL10

L1 L2 L3 N
T1 T2 T3 N



Face plate S1.F056/C10.V11H














Sample image


PADLOCK DEVICE


with F-handle ring


Designation: S1.V840G/A71/D2 Color of F-handle ring: "A" black Color of face plate ring: "7" electric gray Locking position: "1" at 270° (1x90°)

Type of mounting: "D" for type of mounting KS, KL Switch type: "2" for KA-, KG- and KH(R)-switches










MOUNTING

- $1 \pm 2 \ \text{The padlock}$ device has to be mounted by four cylinder head screws from the front.
- 3 Loosen the screw and
- 4 Push it into the handle onto the shaft
- 5 Fasten the screw.







AUXILIARY CONTACTS

(cam operated) for switch type KG20 - KG100C and KH(R)16 - KH(R)25B $\,$

Designation: K0.M510A/1AA-B

Number of contacts: "1" 1 auxiliary contact

Operation of contacts: "A" auxiliary contact(s)

closed in pos. 1 (NO)

Type of version: "A" 1. auxiliary contact module **Type of mounting:** "-B" for type of mounting VE,

VE2, silver contacts

		Voltage (V) AC / DC	
		440 AC	
Rated uninterrupted current lu/lth			
Current (A) Ambient temperatu	re (°C) Peak temper	ature (°C) additional requirements	
10	55	60 Ambient temperature +55°C during 24 hours with peak	s up to +60°C
Rated operational current le			
Utilization category		Voltage (V)	Current (
AC-15		110 - 240	2,5
AC-15		380 - 440	1,
AC-21A		440	
UL60947-4-1 , UL508			
Rated thermal current			
	Current (A)	Ambient temperature (°C) Additional Text	
	10	0-40 -	
GENERAL TECHNICAL INFORMATION			
Size of conductor			
		Cross section (mm²) o	
composition of conductor	Min. / Max. value	No. of conductor per terminal (AWG/kcmil)	Material of the wire
Solid wire	Min.	1 0.5mm²	Copper
Solid wire	Min.	2 0.5mm²	Copper
Flexible wire	Min.	1 0.75mm²	Copper
Flexible wire	Min.	2 0.75mm²	Copper
Flexible wire	Max.	2 AWG 16	Copper
Flexible wire	Max.	2 1.5mm²	Copper
Single-core or stranded wire	Max.	2 AWG 14	Copper
Single-core or stranded wire	Max.	2 1.5mm²	Copper
Flexible wire with ferrule according to DIN 46228	Min.	1 0.5mm²	Copper
Flexible wire with ferrule according to DIN 46228	Max.	2 1mm²	Copper
Flexible wire with ferrule according to DIN 46228	Min.	2 0.5mm ²	Copper
Stripping length			
		Length (mm)	
Recommended screw driver		6	
Type of screw driver		Value	
Cross Screwdriver		PH1	
Slot screwdriver according to DIN 5264		0,6x3,5	
Tightening torque of screws		0,0x3,0	
- ignioning torque or concine	tiahteni	ing torque (Nm)	tightening torque (lb-i
		0,40	3,5
Conditions during transport and storing		·	·
Minimum ter	nperature (°C)	Maximum temperature (°C) additional requi	rements
	-40	85 In case of temp	eratures below -5°C no shock load permissible
General Information			
Text			
- Use only copper wires with or without tinned/silver	-plated individual wires. Solderin	g the end of the wire before wiring is not allowed.	
- Terminals with factory fitted jumper links are tigl	ntened during production for los	ss prevention. When opening the terminal clamps, make sure that	at no factory fitted links get lost and that all w
connections are properly seated.	5,		,

Classification Terminal: Screw terminal

- Switches may only be mounted, connected and set into operation by qualified persons according to the accepted rules of technology.



13			
γ^{1}			
)			
14			

04.10.2025 10:41 AM v3.27 https://www.krausnaimer.com Page 9 of 9